

Use & Care Guide

Gas Slide-In Range



Electrolux

2 Finding Information


MAKE A RECORD FOR FUTURE USE

Brand	
Purchase Date	
Model Number	
Serial Number	

MODEL AND SERIAL NUMBER LOCATION

NOTE

The serial plate is located along the interior side trim of the oven and visible when the door is opened. See picture below.



QUESTIONS?

For toll-free telephone support in the U.S. and Canada: 1-877-4ELECTROLUX (1-877-435-3287)

For online support and internet product information: www.electrolux.com

©2007 Electrolux Home Products, Inc. Post Office Box 212378, Augusta, Georgia 30917, USA All rights reserved. Printed in the USA

TABLE OF CONTENTS

Finding Information	
Make a Record for Future Use	2 Slow Cook 28
Model and Serial Number Location	2 Dehydrating
Questions?	2 Defrosting
Table of Contents	Bread Proofing
0.11	Perfect Turkey 31
Safety	Temperature Probe 32
Important Safety Instructions 4-7	Multi Stage 33-34
Feature Overview	Electronic Control Settings
Your Slide-In Range 8-9	User Preferences35
Oven Rack Supports and Oven Vents 10	User Preference Menu
Removing and Replacing Oven Racks1	USEI FIEIEIEIICE MEHU
Oven Control Pad Functions 12-13	Detting the Glock - Time of Day
	Setting Clock Display - On or Off
Getting Started 14	
Setting Clock at Power Up 14	
Control Panel Display Modes 14	
Temperature Visual Display 14	
Oven Light 15	0 11' 0 1' D I
Control Lock 15	
Setting the Kitchen Timer 15	12 Hour Energy Saving
Surface Cooking 16	Resetting to Default Factory Settings 37
Location of the Burners	
Placement of Burner Heads and Caps	
Proper Burner Adjustment	
Surface Cooking Utensils	7
Flame size	
Setting Surface Controls	Osing the Sen-Clean reature 41
Using the Griddle19	3 Starting the Self-Clean Cycle 42
Using the Gradie	General Cleaning43
Setting the Warmer Oven 20	Care and Cleaning of Stainless Steel 44
Warmer Oven Operation 20	To Remove and Replace Oven Door 44
Onaldan Mada	Special Door Care Instructions 44
Cooking Modes	. Over Light
Baking	
Cook Time	Oleaning the burner Grates,
End Time	Duriter Sups and Burner Fredas
Broiling	. I diddian Enamer docktop
Convection Baking	
Convection Convert	
Rapid Preheat	, , , , , , , , , , , , , , , , , , , ,
Convection Roasting	Solutions
	Jului(U1349-31
	Warranty Information 52

IMPORTANT SAFETY INSTRUCTIONS

Please read all safety instructions before using your new Electrolux range.



⚠ WARNING

To reduce the risk of fire, electrical shock, or injury when using your wall oven, follow basic precautions including the following:

A WARNING If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or death.

FOR YOUR SAFETY:

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- WHAT TO DO IF YOU SMELL GAS:
- · Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, servicer or the gas supplier.



⚠ WARNING

- All ranges can tip.
- Injury to persons could



- Install anti-tip device packed with range.
- See Installation instructions.

To reduce the risk of tipping of the range, the range must be secured by properly installed anti-tip bracket(s) provided with the range. To check if the bracket (s) is installed properly, remove the lower panel or storage drawer and verify that the anti-tip bracket (s) is engaged. Refer to the installation instructions for proper anti-tip bracket(s).

- · Remove all tape and packaging wrap before using the appliance. Destroy the carton and plastic bags after unpacking the appliance. Never allow children to play with packaging material.
- Proper Installation-Be sure your appliance is properly installed and grounded by a qualified technician in accordance in United States with the National Fuel Gas Code ANSI Z223.1 latest edition, and National Electrical Code ANSI/NFPA No. 70 latest edition, and local code requirements, and in Canada with Canadian Standards CAN/CGA B149.1, and CAN/CGA B149.2 and Canadian Electrical Code, CSA C22.1 part 1, and local requirements. Install only per installation instructions provided in the literature package for this range.

Ask your dealer to recommend a qualified technician and an authorized repair service. Know how to disconnect the electrical power to the range at the circuit breaker or fuse box in case of an emergency.

- User Servicing—Do not repair or replace any part of the appliance unless specifically recommended in the manuals. All other servicing should be done only by a qualified technician to reduce the risk of personal injury and damage to the appliance.
- Never modify or alter the construction of a range by removing leveling legs, panels, wire covers, anti-tip brackets/screws, or any other part of the product.

A WARNING Stepping, leaning or sitting on the door or drawer of this appliance can result in serious injuries and may also cause damage to the appliance. Do not allow children to climb or play around the appliance. The weight of a child on an open door may cause the appliance to tip, resulting in serious burns or other injury. An open drawer, when hot, may cause burns.

A WARNING Do not use the oven or warmer drawer (if equipped) for storage.

 Storage in or on Appliance—Flammable materials should not be stored in an oven, near surface units or in the drawer (if equipped). This includes paper, plastic and cloth items, such as cookbooks, plasticware and towels, as well as flammable liquids. Do not store explosives, such as aerosol cans, on or near the appliance. Flammable materials may explode and result in fire or property damage.

⚠ WARNING NEVER use this appliance as a space heater to heat or warm the room. Doing so may result in carbon monoxide poisoning and overheating of the oven.

A CAUTION Do not store items of interest to children in the cabinets above the appliance. Children climbing on the range to reach items could be seriously injured.

- Do not leave children alone. Children should not be left alone or unattended in the area where an appliance is in use. They should never be allowed to sit or stand on any part of the appliance.
- DO NOT TOUCH SURFACE BURNERS, AREAS NEAR THESE BURNERS, OVEN HEATING ELEMENTS OR INTERIOR SURFACES OF THE OVEN OR WARMER DRAWER (if equipped). Both surface burners and oven heating elements may be hot even though surface burner flames are not visible or oven elements are dark in color. Areas near surface burners may become hot enough to cause burns. During and after use, do not touch, or let clothing or other flammable materials touch these areas until they have had sufficient time to cool. Among these areas are the cooktop, surfaces facing the cooktop, the oven vent openings and surfaces near these openings, oven door and window.
- Wear Proper Apparel—Loose-fitting or hanging garments should never be worn while using the appliance. Do not let clothing or other flammable materials contact hot surfaces.

A WARNING Never use your appliance for warming or heating the room.

- Do Not Use Water or Flour on Grease Fires—Smother the fire with a pan lid, or use baking soda, a dry chemical or foam-type extinguisher.
- When heating fat or grease, watch it closely. Fat or grease may catch fire if allowed to become too hot.

⚠ WARNING In case of fire or gas leak, be sure to turn off the main gas shutoff valve.

- Use Only Dry Potholders—Moist or damp potholders on hot surfaces may result in burns from steam. Do not let the potholders touch hot heating surface units or interior oven elements. Do not use a towel or other bulky cloth instead of a potholder.
- Do Not Heat Unopened Food Containers—Build up of pressure may cause the container to burst and result in injury.
- Remove the oven door from any unused appliance if it is to be stored or discarded.
- IMPORTANT—Do not attempt to operate the oven during a power failure. If the power fails, always turn the oven off. If the oven is not turned off and the power resumes, the oven may begin to operate again. Food left unattended could catch fire or spoil.

▲ CAUTION Electronic controllers can be damaged by cold temperatures. When you

6 Safety

use your appliance for the first time, or if it has not been used for a long period of time, make sure that it has been exposed to a temperature above 0°C/32°F for at least 3 hours before connecting it to the power supply.

IMPORTANT INSTRUCTIONS FOR USING YOUR COOKTOP

⚠ WARNING Use proper flame size—Adjust flame size so it does not extend beyond the edge of the utensil. The use of undersized utensils will expose a portion of the burner flame to direct contact and may result in ignition of clothing. Proper relationship of utensil to flame will also improve efficiency.

⚠ WARNING Do not use stove top grills on the burner grates of sealed gas burners. If you use a stove top grill on a sealed gas burner, it will cause incomplete combustion and can result in exposure to carbon monoxide levels above allowable current standards. This can be hazardous to your health.

- Know which knob controls each surface burner. Place a pan of food on the burner before turning it on, and turn the burner off before removing the pan.
- Always turn the knob to the full LITE position when igniting top burners. Visually
 check that burner has lit. Then adjust the flame so it does not extend beyond the edge
 of the utensil.
- Use Proper Pan Size—This appliance is equipped with one or more surface burners of
 different sizes. Select utensils having flat bottoms large enough to cover the surface
 burner. The use of undersized utensils will expose a portion of the surface heating unit to
 direct contact and may result in ignition of clothing. Proper relationship of utensil to the
 surface unit will also improve efficiency.
- Utensil Handles Should Be Turned Inward and Should Not Extend Over Adjacent Surface Burners—To reduce the risk of burns, ignition of flammable materials, and spillage due to unintentional contact with the utensil. The handle of the utensil should be positioned so that it is turned inward, and does not extend over adjacent surface burners.
- **Never Leave Surface Burners Unattended**—Boilovers cause smoking and greasy spillovers that may ignite, or a pan that has boiled dry may melt.
- Protective liners—Do not use aluminum foil to line oven bottom or any other part of the
 appliance. Only use aluminum foil as recommended for baking if used as a cover placed
 on the food. Any other used of protective liners or aluminum foil may result in a risk of
 electric shock or fire or a short circuit.
- Glazed Cooking Utensils—Only certain types of glass, glass/ceramic, ceramic, earthenware, or other glazed utensils are suitable for cooktop service without breaking due to the sudden change in temperature. Check the manufacturer's recommendations for cooktop use.
- **Do not use Searing Grill on the cooktop.** The searing grill is not designed for use on the cooktop. Doing so may result in a fire.
- Do Not Use Decorative Surface burner Covers. If a burner is accidentally turned on, the decorative cover will become hot and possibly melt. Burns will occur if the hot covers are touched. Damage may also be done to the cooktop or burners because the covers may cause overheating. Air will be blocked from the burner and cause combustion problems.

IMPORTANT INSTRUCTIONS FOR USING YOUR OVEN

 Use Care When Opening Door or Drawer—Stand to the side of the appliance when opening the door of a hot oven. Let hot air or steam escape before you remove or replace food in the oven/warmer drawer.

- Keep Oven Vent Ducts Unobstructed. The oven is vented at the front above the oven door or through the rear of cooktop. Touching the surfaces in this area when the oven is operating may cause severe burns. Also, do not place plastic or heat-sensitive items on or near the oven vent. These items could melt or ignite.
- Placement of Oven/Warmer Drawer (if equipped) Racks. Always place oven racks in
 desired location while oven/drawer (if equipped) is cool. Remove all utensils from the rack
 before removing rack. If rack must be moved while oven is hot, use extreme caution. Use
 potholders and grasp the rack with both hands to reposition. Do not let potholders contact
 the hot oven element or interior of the oven/warmer drawer (if equipped).
- **Do not use a broiler pan without its insert.** The broiler pan and grid allow dripping fat to drain and be kept away from the high heat of the broiler.
- Do not cover your broiler or warmer drawer (if equipped) grid with aluminum foil. Exposed fat and grease could ignite.
- **Do not touch a hot light bulb with a damp cloth.** Doing so could cause the bulb to break. Disconnect the appliance or turn off the power to the appliance before removing and replacing light bulb.

IMPORTANT INSTRUCTIONS FOR CLEANING YOUR RANGE

- Clean the range regularly to keep all parts free of grease that could catch fire. Exhaust
 fan ventilation hoods and grease filters should be kept clean. Do not allow grease to
 accumulate. Greasy deposits in the fan could catch fire. Refer to the hood manufacturer's
 instructions for cleaning.
- Cleaners/aerosols—Always follow the manufacturer's recommended directions for use.
 Be aware that excess residue from cleaners and aerosols may ignite causing damage and/or injury.

SELF-CLEANING OVENS:

- Clean in the self-cleaning cycle only the parts of the oven listed in this owner's guide. Before self-cleaning the oven, remove all utensils stored in the oven.
- **Do not clean the oven door gasket.** The door gasket is essential for a good seal. Care should be taken not to rub, damage or move the gasket.
- **Do not use oven cleaners.** No oven cleaner or oven liner protective coating of any kind should be used in or around any part of the oven.
- Remove oven racks. Oven racks will be damaged if left in the oven during a self-cleaning cycle.

ACAUTION The health of some birds is extremely sensitive to the fumes given off during the self-clean cycle of any range. Move birds to another well ventilated room.


IMPORTANT SAFETY NOTICE

The California Safe Drinking Water and Toxic Enforcement Act requires the Governor of California to publish a list of substances known to the state to cause cancer, birth defects or other reproductive harm, and requires businesses to warn customers of potential exposure to such substances.


NOTE

Save these important safety instructions for future reference.


YOUR SLIDE-IN RANGE



YOUR SLIDE-IN RANGE



OVEN RACK SUPPORTS & OVEN VENTS



Installing Oven Rack Supports


ALWAYS INSTALL OVEN RACK SUPPORT BEFORE TURNING ON THE OVEN (WHEN THE OVEN IS COOL).

To install oven rack support, insert the supports by pushing them downward into the two brackets on each side of the oven interior, as shown below.

To remove the oven rack support for a self-clean cycle, pull up the support to disengage them from the brackets. If the rack supports are not removed, the self-clean cycle won't start.


Oven Rack Positions

This oven is equipped with ladder rack supports with 7 positions to accomodate precisely every mode of cooking.



Oven Vent Location

The oven is vented above each door. When the oven is on, warm air is released through the vents. This venting is necessary for proper air circulation in the oven and good baking results.



REMOVING AND REPLACING OVEN RACKS


Removing Sliding Oven Racks

- 1. With the rack in its closed position; grasp the rack and the sliders at once.
- 2. Slightly lift the rack and sliders and pull it to clear the first bracket.
- 3. Pull the rack and sliders until the second bracket stops the rack.
- 4. Lift the rack and sliders and carefully remove them from the oven.

Refer to the care and cleaning section for directions on how to clean the racks.

Replacing Sliding Oven Racks

To replace the oven racks, follow the intructions above in reverse order.




Removing Non-Sliding Oven Rack

Simply pull the rack and slightly tilt it upward when the rack hits its stop position.

Replacing Non-Sliding Oven Rack


Insert the rack into the oven rack supports by inserting the rack openings into the rack supports. Be sure the rack is at the same position on each oven rack support on both sides.



A WARNING Always arrange the oven racks when the oven is cool (prior to operating the oven). Always use oven mitts when using the oven.

TOWARD BACK OF OVEN

OVEN CONTROL PAD FUNCTIONS



- 1 Light Pad- Used to turn the oven light on and off.
- **2** Bake Pad- Used to enter the normal baking mode temperature.
- 3 Broil Pad- Used to select the variable broil mode.
- 4 Convection Bake Pad- Used to select the convection baking mode.
- **5** Convection Roast Pad- Used to select the convection roasting mode.
- **6 Keep Warm Pad-** Used to select the keep warm mode.
- 7 Slow Cook Pad- Used to select the slow cook mode.
- 8 Control Lock Pad- Used to disable all oven function.
- **9** Perfect Turkey Pad- Used to select the perfect turkey cooking mode.
- 10 Defrost Pad- Used to select the defrost mode.
- **11 Dehydrate Pad-** Used to select the dehydrate mode.
- 12 My Favorite 1 Pad- Used to save or recall the saved favorite 1 cooking mode.
- **13** My Favorite 2 Pad- Used to save or recall the saved favorite 2 cooking mode.
- 14 My Favorite 3 Pad- Used to save or recall the saved favorite 3 cooking mode.
- 15 Multi Stage Pad- Used to enter up to three subsequent modes.
- **16** Cook Options Pad- Used to light up the cooking options pads.
- 17 Cook Time Pad- Used to set a cooking duration time.
- **18 End Time Pad-** Used to select the time at which the cooking will end.
- **19 Probe Pad-** Used to activate the meat probe mode.
- **20** Rapid Preheat Pad- Used to preheat the oven to the desired temperature..

OVEN CONTROL PAD FUNCTIONS (CONTINUED)

33 31 1 **①** 2 3 timer on-off 31) 5 4 6 8 0 conv lo hi **CANCEL START**

- 21 Bread Proof Pad- Used to select the bread proof mode.
- 22 Clean Pad- Used to select the self-cleaning mode.
- **23 Upper Oven Pad-** Used to activate the upper oven for cooking operation.
- **24** Warmer Oven Pad- Used to activate the warmer oven for warming operation.
- **25** Lite Pad- Used to start a 2 hours self-clean cycle.
- 26 Med Pad- Used to start a 3 hours self-clean cycle.
- 27 Heavy Pad- Used to start a 4 hours self-clean cycle.
- **28 Conv. Convert Pad-** Used to convert a standard temperature to a convection temperature.
- 29 User Preference Pad- Used to bring the user preference menu in the display.
- **30** Cancel Pad- Used to cancel any function previously entered except the time of day and minute timer. Push Cancel pad to stop cooking.
- 31 Timer Pads- Used to set or cancel the minute timer.
- 32 Start Pad- Used to start all oven functions.
- **33 0 Thru 9 Number Pads** Used to enter temperature and times.
- **34 Io Pad** Used to lower the temperature and times.
- **35 + hi Pad** Used to raise the temperature and times.

14 Getting Started

SETTING CLOCK AT POWER UP

When the unit is first plugged in, or when the power supply to the range has been interrupted, the timer in the display will flash with "12:00". The clock cannot be set when the oven is on. If an invalid time of day is entered, the control will triple beep to prompt you to re-enter a valid time of day.


To set the clock (example for 1:30):

- 1. Press 1 3 0 pads to set the time of day to 1:30. The pads hi or lo can also be pressed to raise or lower the actual time displayed.
- 2. Press **START** to accept the changes or **CANCEL** to start with a time of 12:00.

CONTROL PANEL DISPLAY MODES

Sleep Mode:

Your control will remain in a sleep mode when not in use. Only the clock will display during this mode. You will need to wake the control to begin any function.



To wake the control, touch within the display panel. After 2 minutes without activity the control will beep and go back into sleep mode.

To start a cooking feature you must select either the upper oven or the lower oven. User preferences will be available during this mode as well as timers, oven light and the control lock.

TEMPERATURE VISUAL DISPLAY

Your oven is equipped with a temperature visual display for each oven. When a cooking mode is set, the actual temperature will be shown in the display and will rise as the unit preheat. When the unit has reached its target temperature, a chime will sound to remind you to place the food in the oven. This feature will be active with some cooking modes; bake, convection bake, convection roast and perfect turkey. The cooking modes which does not feature the temperature visual display will be noted in their descriptions.

NOTE: The lowest temperature that can be displayed is 100°F.

OVEN LIGHT

Your appliance includes "theater" style oven lighting feature that gradually lights both the upper and lower oven interiors to full brightness. The upper oven is equipped with 2 halogen lights and the lower oven is equipped with 1 incandescent light. The oven lights will turn on automatically when the oven door is opened. The oven light may be turned on when the door is closed by using the oven light pad located on the control panel. The oven light key will toggle the lights in both ovens at the same time at full intensity.



To toggle the Oven Lights ON and OFF:

1. Press **OVEN LIGHT** Ω .

CONTROL LOCK

The Control Lock feature automatically locks the upper oven door and the control panel. The Control Lock is only allowed when the oven is turned OFF (not active). DOOR LOCK will flash in the display for 20 seconds or until the door has finished locking. Once the door has been locked, **Loc** message will appear in the upper display. Do not attempt to open the oven door while DOOR LOCK is flashing.



To toggle the Control Lock ON and OFF:

1. Keep **CONTROL LOCK** pressed for 3 seconds.

SETTING THE KITCHEN TIMER

This unit is equipped with 2 Kitchen Timers which serves as extra timers in the kitchen that will beep when the set time has run out. It does not start or stop cooking. The Timer feature can be used during any of the other oven control functions and cooking modes.




To set the Timer (example for 5 minutes):

- 1. Press **TIMER** ①. "**00:00**" will appear in the display.
- 2. Press (5) pad to set the timer to 5 minutes. The pads $_{hi}^{+}$ or $_{lo}^{-}$ can also be pressed to raise or lower the actual time displayed.
- 3. Press again **TIMER** ① to accept and start the countdown.
- 4. When the set time has run out, "00:00" will be displayed and the TIMER ① pad will flash. The clock will sound a chime that will be repeated at regular intervals until the TIMER ① pad is pressed.

To cancel the Timer before the set time has run out:

Press **TIMER** ①. The display will return to the time of day.

LOCATIONS OF THE BURNERS



The cooktop is equipped with different sized burners.

The surface burners are located on the cooktop as follows (See Figure):

- a **5 000 BTU** (natural gas) burner located at the right rear position;
- a **18 000 BTU** (natural gas) burner located at the right front position;
- a 9 500 BTU (natural gas) burner located at the left front position;
- a 14 000 BTU (natural gas) burner located at the left rear position.

PLACEMENT OF BURNER HEADS AND CAPS

For the 18 000 BTU burner:

Place the burner head over the gas orifice (Figure 1). Be careful not to damage the electrode while placing the burner head over the orifice. Make sure electrode fits correctly into slot in burner head.




Figure 1

Figure 2

For all burners:

Place a burner cap on each burner head (see Figure 2), matching the cap size to the head size. The cap for each burner has an inner locating ring which centers the cap correctly on the burner head. Be sure that all the burner caps and burner heads are correctly placed BEFORE using your appliance.

Make sure each burner cap is properly aligned and level.

Turn the burner on to determine if it will light. If the burner does not light, contact a Service Center. Do not service the sealed burner yourself.

PROPER BURNER ADJUSTMENTS

The color of the flame is the key to proper burner adjustment. A good flame is clear, blue and hardly visible in a well-lighted room. Each cone of flame should be steady and sharply defined. Adjust or clean burner if flame is yellow-orange. To clean burner, see instructions under **General Care & Cleaning**.

SURFACE COOKING UTENSILS

*GOOD



- Flat bottom and straight sides.
- · Tight fitting lids.
- Weight of handle does not tilt pan.
 Pan is well balanced.
- Pan sizes match the amount of food to be prepared and the size of burner.
- Made of material that conducts heat well.
- · Easy to clean.

POOR

· Curved and warped pan bottoms.



 Pan overhangs unit by more than 2.5 cm (1").



Heavy handle tilts pan.



• Flame extends beyond unit.



Check for flatness by rotating a ruler across the bottom. There should be no gaps between the pan and ruler.

Pans should have flat bottoms.


* Specialty pans such as lobster pots, griddles and pressure cookers may be used but must conform to the above recommended cookware requirements.

Note: Always use a utensil for its intended purpose. Follow manufacturer's instructions. Some utensils were not made to be used in the oven or on the cooktop.

FLAME SIZE

For most cooking, start on the highest control setting and then turn to a lower one to complete the process. Use the chart below as a guide for determining proper flame size for various types of cooking. The size and type of utensil used and the amount of food being cooked will influence the setting needed for cooking.

For deep fat frying, use a thermometer and adjust the surface control knob accordingly. If the fat is too cool, the food will absorb the fat and be greasy. If the fat is too hot, the food will brown so quickly that the center will be undercooked. Do not attempt to deep fat fry too much food at once as the food will neither brown nor cook properly.



*Flame Size Type of Cooking High Flame Start most foods; bring water to a boil; pan broiling Medium Flame Maintain a slow boil; thicken sauces, gravies; steam Low Flame Keep foods cooking; poach; stew

*These settings are based on using medium-weight aluminum pans with lids. Settings may vary when using other types of pans.

Never extend the flame beyond the outer edge of the utensil. A higher flame simply wastes heat and energy, and increases your risk of being burned by the flame.

SETTING SURFACE CONTROLS

Your cooktop may be equipped with any combination of the following burners:

Simmer Burner: best used for simmering delicate sauces, etc.

Standard Burner: used for most all surface cooking needs.

Large Burner: best used when bringing large quantities of liquid to temperature and when preparing larger quantities of food.

Regardless of size, always select a utensil that is suitable for the amount and type of food being prepared. Select a burner and flame size appropriate to the pan. Never allow flames to extend beyond the outer edge of the pan.

Your cooktop is also equipped with 270° rotation flame control valves. These valves provide enhanced control of the burner flame. Each burner lights automatically from an electric ignitor when its control knob is turned to the **LITE** position.

A CAUTION

Do not place plastic items such as salt and pepper shakers, spoon holders or plastic wrappings on top of the cooktop when it is in use. These items could melt or ignite. Potholders, towels or wood spoons could catch fire if placed too close to a flame.



To operate the surface burner:

- 1. Place cooking utensil on burner.
- 2. Push in and turn the Surface Control knob to XX (LITE). Note: All electronic ignitors will click at the same time. However, only the burner you are turning on will ignite.
- 3. Visually check that the burner has lit.
- 4. Turn the control knob to the desired flame size. The control knobs do not have to be set at a particular mark. Use the guides and adjust the flame as needed. **DO NOT** cook with the Surface Control knob in the XX position. (The electronic ignitor will continue to click if left in the XX position, causing premature wear.)

In the event of an electrical power outage, the surface burners can be lit manually. To light a surface burner, hold a lit match to the burner head, then slowly turn the Surface Control knob to XX. Use caution when lighting surface burners manually.

USING THE GRIDDLE

The griddle is intended for direct food cooking and can be used on both sides. **Do not** use pans or other cookware on the griddle. Doing so could damage the finish. With the grate in position over the burner, set the griddle on top of the grate positioning the notches in the griddle over the grate fingers (refer to figures 1 for optimal positioning).




Figure 1

A CAUTION

Always place the griddle on the grate before to turn on the burner.

Always use potholders to remove the griddle from the grate. Allow the griddle to cool before removing. Do not set hot griddle on surfaces that cannot withstand high heat; such as countertops.

Be sure the griddle is positioned correctly and stable before use to prevent hot spills and possible burns.

WARMER OVEN OPERATION

To Operate the Warmer Oven

The purpose of the warmer oven is to keep hot cooked foods at serving temperature. Always start with hot food. It is not recommended to heat cold food in the warmer drawer.

All food placed in the warmer oven should be covered with a lid or aluminum foil to maintain moisture and softness. Do not cover crisp foods. **Do not use plastic wrap to cover food. Plastic may melt onto the drawer and be very difficult to clean.**

Use only dishware, utensils and cookware recommended for oven use in the warmer drawer.

Arranging Warmer Oven Rack Positions

Set the warmer oven rack in the vertical position as shown below.







Downward Position

The rack can be used in 2 ways:

- In the upright position to allow low profile food items to be placed both under and on top of the rack (for example, rolls or biscuits on top of the rack and a casserole dish under).
- In the downward position to allow you to place light weight food items and empty dishware (for example, rolls or pastries and dinner plates).

Use the warmer drawer to keep hot foods hot such as: vegetables, gravies, meats, casseroles, biscuits and rolls, pastries and heated dinner plates.

To set a Keep Warm Temperature of 170°F:

- 1. Arrange interior warmer oven rack.
- Select oven by pressing WARMER OVEN WARMER OVEN OVEN.
- 3. Press **KEEP WARM** .
- 4. Press **START** ()
- 5. The Cook Time, Timer and End Time features can be set to control your warming time (read their sections for directions).
- 6. Remove food. Always use oven mitts when removing hot pans from the oven.
- 7. Press **CANCEL** (7) to stop or cancel the Keep Warm feature at any time.

NOTE: The lower oven will not operate when the upper oven is set for self-cleaning or if the control lockout feature is active.

⚠ WARNING KEEP CHILDREN AWAY FROM THE WARMER OVEN WHEN HOT. FAILURE TO DO SO CAN RESULT IN BURNS.


A CAUTION Always use oven mitts when removing food from the lower oven. The lower oven rack, compartment, cookware/plates may be hot.

BAKING

This mode is best used for your standard recipes. The hidden bake element is used to heat the air and maintain temperature. The temperature probe can be used in this cooking mode. The upper oven can be programmed to bake at any temperature from 170°F to 550°F with a default temperature of 350°F.

Upper Oven Baking Tips:

- Always preheat your oven before using the bake mode.
- During preheat, the 3 elements and the convection fan are used in cycle to quickly heat the oven.
- Use only one rack and center the pans as much as possible.
- If using two racks, place the oven racks in positions 2 and 6.
- Allow 2" to 4" (5,1 to 10,2cm) around the utensil(s) for proper air circulation.
- Be sure the pans do not touch each other, the door, sides or back of the oven.



To set a Bake Temperature of 350°F:

- 1. Arrange interior oven racks.
- 2. Select oven by pressing UPPER OVEN OVEN
- 3. Press BAKE ___
- 4. Press **START** (1). The oven display shows **PRE-HEATING**.
- 5. Place food in the oven when the chime signals and temperature display shows that the oven has reached the set target temperature and the **PRE-HEATING** message disappear.
- 6. Cook Time, Timer and End Time features can be set to control your cooking time in both ovens (read their sections for directions). The Temperature Probe and Rapid Preheat features can be used only with the upper oven.
- 7. Remove food. Always use oven mitts when removing hot pans from the oven.
- 8. Press **CANCEL** (to stop or cancel the Bake feature at any time.

To change to a Bake Temperature of 425°F:

- 1. Select oven by pressing **UPPER OVEN** OVEN.
- 2. Press the **HI** ⁺_{hi} or **LO** ⁻_{lo} pads to get to the desired temperature.
- 3. Press START ().

Baking Problems

Refer to the Baking Problems Table in the Solutions to Common Problems section of this manual.

22 Cooking Modes

COOK TIME



Cook Time allows the oven to be set to cook for a set length of time and shut off automatically. The time remaining will always be shown in the timer section of the display. The oven will shut off and will beep when the countdown is finished. This feature can be used with Bake, Convection Bake, Convection Roast, Slow Cook, Keep Warm, Defrost, Bread Proof, Dehydrate and Perfect Turkey cooking modes. It can also be part of a Multi-Stage sequence.

To set a timed cooking (example is a 450°F Bake for 30 minutes):

- 1. Select oven by pressing **UPPER OVEN** OVEN.
- Press BAKE ___. The temperature numbers will blink in the display.
- 3. Enter temperature needed; (4)(5)(0).
- Press COOK OPTIONS (V) to bring up the cook options items.
- 5. Press COOK TIME (1).
- 6. Enter time needed; (3)(0).
- 7. Press **START** ①. The oven will start heating. The cook time will start counting down for the set time.
- 8. Press **CANCEL** (to stop the audible alarm or to cancel cooking at anytime.

END TIME



End Time allows the oven to be set to shut off automatically at a set time of day. The oven control will calculate the remaining time by itself. The time remaining will always be shown in the timer section of the display. The oven will shut off and will beep when the countdown is finished. This feature can be used with Bake, Convection Bake, Convection Roast, Slow Cook, Keep Warm, Defrost, Dehydrate, Clean and Bread Proof cooking modes. This oven can be programmed with Cook Time and End Time to start and stop by itself at the right time.

To set a delayed timed cooking (example is a 450°F Bake for 30 minutes which will end at 6:00PM):

- 1. Select oven by pressing **UPPER OVEN** OVEN.
- 2. Press **BAKE** . The temperature numbers will blink in the display.
- 3. Enter temperature needed; (4)(5)(0).
- 4. Press COOK OPTIONS (v) to bring up the cook options items.
- 5. Press COOK TIME (1).
- 6. Enter time needed; 30.
- 7. Press **END TIME** (1).
- 8. Enter time of day needed; 600.
- Press START

 . The time remaining will be shown in the display.
- 10. Press **CANCEL** (to stop the audible alarm or to cancel cooking at anytime.

A CAUTION Use caution with the **COOK TIME** or **END TIME** features. Use the automatic timer when cooking cured or frozen meats and most fruits and vegetables. Foods that can easily spoil such as milk, eggs, fish, meat or poultry, should be chilled in the refrigerator first. Even when chilled, they should not stand in the oven for more than 1 hour before cooking begins, and should be removed promptly when cooking is completed. Eating spoiled food can result in sickness from food poisoning.

BROILING


This mode is best for meats, fish and poultry up to 1" thick. Broiling is a method of cooking tender cuts of meat by direct heat under the broil element of the oven. The high heat cooks quickly and gives a rich, brown outer appearance. The temperature probe cannot be used with this mode. The oven can be programmed to broil at any temperature from 300°F to 550°F with a default temperature of 550°F.

Broiling Tips:

- For optimum browning, preheat the broil element for 2 minutes.
- Broil one side until the food is browned; turn and cook on the second side. Season and serve.
- Always pull the rack out to the "stop" position before turning or removing food.
- Always use the broiler pan and its grid when broiling. It allows the dripping grease to be kept away from the high heat of the broil element (see Figure 1).
- DO NOT use the broil pan without the insert. DO NOT cover the broil pan insert with foil. The exposed grease could catch fire. DO NOT use the roasting rack when broiling.

To set a Broil Temperature of 550°F:

- 1. Arrange interior oven racks.
- 2. Select oven by pressing **UPPER OVEN** OVEN.
- 3. Press **BROIL** .
- 4. Press **START** (1).
- 5. Place food in the oven after 2 minutes.
- Turn food when the top side is browned and cook on the second side.
- 7. Remove food. Always use oven mitts when removing hot pans from the oven.
- 8. Press **CANCEL** To stop or cancel the Broil feature at any time.



Broiling Times

Electric Wall Oven E	Broiling Tab	le Recomme	ndations		
Food	Rack	Temp	Cook Time		
Item	Position	Setting	1st side	2nd side	Doneness
Steak 1" thick	7	550° F	6:00	4:00	Rare
	7	550° F	7:00	5:00	Medium
Pork Chops 3/4" thick	7	550° F	8:00	6:00	Well
Chicken - Bone In	5	450° F	20:00	10:00	Well
Chicken - Boneless	7	450° F	8:00	6:00	Well
Fish	7	500° F	13:00	0:00	Well
Shrimp	5	550° F	5:00	0:00	Well
Hamburger 1" thick	7	550° F	9:00	7:00	Medium
-	5	550° F	10:00	8:00	Well

A WARNING Should an oven fire occur, keep the oven door closed and turn off the oven. If the fire continues, throw baking soda on the fire or use a fire extinguisher. **DO NOT** put water or flour on the fire. Flour may be explosive and water can cause a grease fire to spread and cause personal injury.

CONVECTION BAKING





This mode of cooking enables you to obtain the best culinary results when baking with multiple pans and racks. Multiple rack baking may slightly increase cook time for some foods but the overall result is time saved. Most foods cooked in a standard oven will cook faster and more evenly with Convection Bake. Convection baking uses the hidden bake element, the hidden convection element and a fan to circulate the oven's heat evenly and continuously within the oven. The temperature probe can be used in this cooking mode. The oven can be programmed for Convection baking at any temperature between 300°F to 550°F with a default temperature of 350°F.

Convection Baking Tips:

- Always preheat your oven before using the Convection Bake mode.
- If your recipe cooking temperature has already been converted for convection baking there is no need to reduce your oven temperature. If your recipe has not had the temperature converted for convection baking you can easily reduce the temperature using the Convection Convert feature. Please see Convection Convert section on next page for further instruction on temperature conversion.
- Use tested recipes with times adjusted for convection baking when using this mode. With single rack convection baking some foods may have as much as a 25% reduction in cook time; check food at minimum time. Time reductions will vary depending on the amount and type of food to be cooked.
- When using Convection Bake with a single rack, place oven rack in position 3 or 4. If cooking on multiple racks, place the oven racks in positions 2 and 6 or 1, 4 and 7.
- Most bakeries (except cakes) should be baked on pans with no sides or very low sides to allow heated air to circulate around the food.
- Food baked on pans with a dark finish will cook faster.

To set a Convection Bake Temperature of 350°F:

- 1. Arrange interior oven racks.
- 2. Select oven by pressing **UPPER OVEN** OVEN.
- 3. Press CONVECTION BAKE Y.
- 4. Press **START** ①. The oven display shows **PRE-HEATING**.
- 5. Place food in the oven when the chime signals and temperature display shows that the oven has reached the set target temperature and the **PRE-HEATING** message disappear.
- 6. The Temperature Probe, Cook Time, Timer, End Time and Rapid Preheat features can be set to control your cooking time (read their sections for directions).
- 7. Remove food. Always use oven mitts when removing hot pans from the oven.
- 8. Press **CANCEL** (to stop or cancel the Convection Bake feature at any time.

CONVECTION CONVERT

The Convection Convert pad is used to automatically convert a standard baking recipe for convection baking. When set properly, this feature is designed to display the actual converted (reduced) temperature in the display. Convection Convert may ONLY be used with a Convection Bake cooking mode. It can be used with the features End Time and Cook Time (see their sections for directions). If convection conversion is used with the cook time and end time features, "CF" (check food) will be displayed when 75% of the bake time is complete. At this time the oven control will sound 3 long beeps at regular intervals until baking had finished. When the bake time has completely finished the control will beep at regular interval until the CANCEL pad is pressed.

NOTE: To use this feature with the COOK TIME potion, the COOK TIME pad must be pressed before the CONVECTION CONVERT pad.



Changing from a normal bake temperature to a convection bake temperature:

- 1. Select oven by pressing **UPPER OVEN** OVEN OVEN
- 2. Press CONVECTION BAKE
- 3. Press COOK OPTIONS (\checkmark). The cook options items will light up.
- 4. Press **CONVECTION CONVERT** > The temperature displayed will be 25°F lower than what it used to be.
- 5. Press **START** to begin the convection baking (see Convection Baking section for more informations).

RAPID PREHEAT

The Preheat feature will bring the oven up to temperature faster than a regular preheat and then indicate when to place the food in the oven. Preheating is not necessary when roasting or cooking casseroles. The oven can be programmed to preheat with some of the cooking modes; Bake, Convection Bake and Convection Roast.



IMPORTANT: The rapid preheat feature is for single rack ONLY. The heat distribution with multiple rack will be uneven.

To set a rapid preheat (example is for a 350°F Bake):

- 1. Select oven by pressing **UPPER OVEN** OVEN.
- 3. Press COOK OPTIONS (). The cook options items will light up.
- Press RAPID PREHEAT >> .
- 5. Press **START (**) to begin the baking with the rapid preheat feature enabled.
- 6. Place food in the oven when the chime signals and PRE-HEATING message disappears indicating that the oven has reached the set target temperature.

CONVECTION ROASTING



This mode is best for cooking tender cuts of beef, lamb, pork and poultry. Use this mode when cooking speed is desired. The Convection Roasting gently browns the exterior and seals in the juices. Convection roasting uses the hidden bake element, the hidden convection element, the broil element and a fan to circulate the oven's heat evenly and continuously within the oven. The temperature probe can be used in this cooking mode. The oven can be programmed for Convection Roasting at any temperature between 300°F to 550°F with a default temperature of 350°F.

Convection Roasting Tips:


- Use the broiler pan and grid, and the roasting rack (Figure 1). The broiler pan will catch grease spills and the grid will help prevent spatters. The roasting rack will hold the meat.
- Place an oven rack on rack position 2 (next-bottom).
- Make sure the roasting rack is securely seated on the grid in the broiler pan. The roasting
 rack fits on the grid allowing the heated air to circulate under the food for even cooking and
 helps to increase browning on the underside.
- There is no need to reduce the convection temperature or to use the Convection Convert feature with this cooking mode.
- DO NOT use the broiler pan without the grid or cover the grid with aluminum foil.
- Always pull the rack out to the stop position before removing food.
- Position food (fat side up) on the roasting rack.

To set a Convection Roast Temperature of 350°F:

- 1. Arrange interior oven racks.
- 2. Select oven by pressing UPPER OVEN OVEN OVEN
- 3. Press CONVECTION ROAST .
- 4. Press **START** ().
- 5. The Temperature Probe, Cook Time, Timer, End Time and Rapid Preheat features can be set to control your cooking time (read their sections for directions).
- 6. Remove food. Always use oven mitts when removing hot pans from the oven.
- 7. Press **CANCEL** \bigcirc to stop or cancel the Convection Roast feature at any time.

Conve	ction Roasting Chart	_	_		
Meat		Weight	Oven Temp	Internal Temp	Min per lb.
Beef	Standing rib roast	4 to 6 lbs.	350° F	*	25-30
	Rib eye roast	4 to 6 lbs.	350° F	*	25-30
	Tenderloin roast	2 to 3 lbs.	400° F	*	15-25
Poultry	Turkey, whole**	12 to 16 lbs.	325° F	180° F	8-10
	Turkey, whole**	16 to 20 lbs.	325° F	180° F	10-15
	Turkey, whole**	20 to 24 lbs.	325° F	180° F	12-16
	Chicken	3 to 4 lbs.	350-375° F	180° F	12-16
Pork	Ham roast, fresh	4 to 6 lbs.	325° F	160° F	30-40
	Shoulder blade roast	4 to 6 lbs.	325° F	160° F	20-30
	Loin	3 to 4 lbs.	325° F	160° F	20-25
	Pre-cooked ham	5 to 7 lbs.	325° F	160° F	30-40

^{*} For beef: med rare 145°F, med 160°F, well done 170°F



^{**} Stuffed turkey requires additional roasting time. Shield legs and breast with foil to prevent overbrowning and dying of the skin.

KEEP WARM

This mode is best for keeping oven hot foods warm for serving after cooking has finished. The Keep Warm feature uses the hidden bake element to maintain the temperature within the oven. The Keep Warm feature may be used with Multi-Stage (refer to its section for directions) if you wish to have the Keep Warm feature turn ON automatically when cooking has finished. The oven can be programmed for Keep Warm at any temperature between 150°F to 190°F with a default temperature of 170°F.



Keep Warm Tips for Upper Oven:

- · Always start with hot food.
- Do not use the Keep Warm feature to heat cold food.
- Food in heat-safe glass and glass ceramic containers may need higher temperature settings compared to food in regular containers.
- Avoid repeated openings of the oven, it will allow hot air to escape and the food to cool.
- · Aluminum foil may be used to cover food to increase moisture content.

Keep Warm Tips for Warmer Oven:

• Follow recommandations for lower oven cooking modes in the **Setting Warmer Oven** section of this manual.

To set a Keep Warm Temperature of 170°F:

- 1. Arrange interior oven racks (for upper oven only).
- 2. Select oven by pressing **UPPER OVEN** OVEN OVEN OVEN OVEN.
- 3. Press **KEEP WARM** .
- 4. Press START ①.
- 5. The Multi-Stage, Cook Time, Timer and End Time features can be set to control your warming time (read their sections for directions).
- 6. Remove food. Always use oven mitts when removing hot pans from the oven.
- 7. Press **CANCEL** (7) to stop or cancel the Keep Warm feature at any time.

SLOW COOK



This mode may be used to cook foods more slowly, at lower oven temperatures and provide cooking results much the same way as a Slow Cooker or Crock-Pot. The Slow Cook feature is ideal for roasting beef, pork & poultry. Slow Cooking meats may result in the exterior of meats becoming dark but not burnt. This is normal. The Slow Cook mode uses the hidden bake element to maintain a low temperature in the oven. The temperature probe cannot be used in this cooking mode. There are 2 settings available, high (HI) or low (LO). The maximum cook time for the Slow Cook feature is 12 hours unless the oven control has been changed to the Continuous Bake mode or the Sabbath mode has been activated.

Slow Cook Tips:

- Completely thaw all frozen foods before cooking with the Slow Cook feature.
- When using a single rack, position it in the center of the oven.
- Position multiple racks to accommodate size of cooking utensils when cooking multiple food items.
- Do not open the oven door often or leave the door open when checking foods. If the oven heat escapes often, the Slow Cook time may need to be extended.
- Cover the foods to keep them moist or use a loose or vented type cover to allow foods to turn crisp or brown.
- Cook times will vary; depending on the weight, fat content, bone & the shape of the meat.
- Use the recipe's recommended food temperature and a food thermometer to determine when the food is done.
- Preheating the oven will not be necessary when using the Slow Cook feature.
- Add any cream or cheese sauces during the last hour of cooking.

To set a Slow Cook:

- 1. Arrange interior oven racks and place food in the oven.
- 2. Select oven by pressing **UPPER OVEN** OVEN.
- 3. Press SLOW COOK :
- 4. Press ⁺_{hi} for high (**HI**) setting or ⁻_{lo} low (**Lo**) setting.
- Press START ().
- 6. The Cook Time, Timer and End Time features can be set to control your Slow Cook time (read their sections for directions).
- 7. Remove food. Always use oven mitts when removing hot pans from the oven.
- 8. Press **CANCEL** \bigcirc to stop or cancel the Slow Cook feature at any time.

DEHYDRATING

This mode dries foods with heat from the convection element. The heat is circulated throughout the oven by the convection fan. Dehydrating is used to dry and/or preserve foods such as fruits, meats, vegetables and herbs. This mode holds an optimum low temperature while circulating the heated air to slowly remove moisture. The oven can be programmed for Dehydrating at any temperature between 100°F to 225°F with a default temperature of 120°F.



Dehydrating Tips:

- Do not preheat the oven.
- Multiple racks can be used simultaneously.
- Drying times vary depending on the moisture and sugar content of the food, the size of the pieces, the amount being dried and the humidity in the air.
- Check food at the minimum drying time.
- Treat fruits with antioxidants to avoid discoloration.
- Consult a food preservation book or a library for additional information.

To set a Dehydrate Temperature of 120°F:

- 1. Arrange interior oven racks and place food.
- 2. Select oven by pressing **UPPER OVEN** OVEN OVEN.
- Press START ①.
- 5. Remove food. Always use oven mitts when removing hot pans from the oven.
- 6. Press **CANCEL** (to stop or cancel the Dehydrate feature at any time.

DEFROSTING

This mode uses a fan controlled defrosting to quickly warm your food at the room's temperature. Suitable for delicate items such as cream cakes, this light defrost circulates room temperature air around the food slowly, defrosting it hygienically in less time!

Defrosting Tips:

Place an oven rack on rack position 2 (next-bottom).

To set a Defrost:

- 1. Arrange interior oven racks and place food in the oven.
- 2. Select oven by pressing **UPPER OVEN** OVEN.
- 3. Press **DEFROST** 🔆
- 4. Press **START** to start the defrosting. A "dEF" message is displayed when active.
- 5. The Cook Time, End Time and Timer features can be set to control your Defrost time (read their sections for directions).
- 6. Remove food.
- 7. Press CANCEL to stop or cancel the Defrost feature at any time.

A CAUTION It is not recommended to use food that can spoil due to bacteria growth. Defrost only items which are recommended for countertop thawing.



BREAD PROOFING



Proofing bread prepares the dough for baking by activating the yeast. This feature is ideal for proofing, or rising bread dough. The oven can be programmed for Bread Proofing at any temperature between 85°F to 100°F with a default temperature of 100°F.

Bread Proofing Tips:

- No need to preheat for this feature.
- Proof bread until dough has doubled in bulk.
- For best results, place a shallow pan with 1 to 3 cups of boiling hot water on the lowest rack position to keep the air moist inside the oven cavity.
- Allow at least 1" between edge of pan and walls of the oven.
- Limit frequent door openings to prevent losing heat and lengthening proofing time.

To set a Bread Proof temperature of 100°F:

- 1. Arrange interior oven racks and place bread dough in the oven.
- 2. Select oven by pressing **UPPER OVEN** OVEN.
- 3. Press BREAD PROOF .
- 4. Press **START** () to begin the bread proofing.
- 5. The Cook Time, Timer and End Time features can be set to control your Bread Proof time (read their sections for directions).
- 6. Remove food.
- 7. Press **CANCEL** (to stop or cancel the Bread Proof feature at any time.

To change a Bread Proof temperature while the function is active:

- 1. Select oven by pressing **UPPER OVEN** OVEN.
- 2. Press the **HI** ⁺_{bi} or **LO** ⁻_{lo} pads to get to the desired temperature.
- 3. Press **START (**) to continue the bread proofing with the new setting.

PERFECT TURKEY

This mode uses the temperature probe to control precisely the cooking of a perfect turkey. The convection system gently browns the turkey's exterior and seals in the juices. The temperature probe is **required** with this cooking mode (read its section on next page for more details). The oven can be programmed for Perfect Turkey at any temperature between 170°F to 550°F with a default temperature of 325°F. The probe default temperature for the perfect turkey feature is 180°F.



Perfect Turkey Tips:

- Thaw the turkey in the refrigerator at least 24 hours per 5 lbs before cooking the bird.
- Use the broiler pan and grid, and the roasting rack. The broiler pan will catch grease spills and the grid will help prevent spatters. The roasting rack will hold the turkey.
- Place an oven rack on next-bottom rack position.
- Make sure the roasting rack is securely seated on the grid in the broiler pan. The roasting
 rack fits on the grid allowing the heated air to circulate under the food for even cooking and
 helps to increase browning on the underside.

To set a Perfect Turkey:

- 1. Arrange interior oven racks and place food in the oven.
- 2. Insert the meat probe into the bird and connect it in the oven (read the probe section on next page for more details).
- 3. Select oven by pressing **UPPER OVEN** OVEN.
- 4. Press **PERFECT TURKEY 3**. A temperature can be entered if another value than the default is needed.

Optional: Press **PROBE** if you wish to change the probe target temperature (see PROBE section).

- 5. Press **START** ().
- 6. Remove food from the oven when the probe chime signals that the bird internal temperature has reached its target.
- 7. Press **CANCEL** \bigcirc to stop or cancel the Perfect Turkey feature at any time.

Perfec	t Turkey Chart				
		Weight	Oven Temp	Internal Temp	Min per lb.
Poultry	Turkey, whole*	12 to 16 lbs.	325° F	180° F	8-10
	Turkey, whole*	16 to 20 lbs.	325° F	180° F	10-15
	Turkey, whole*	20 to 24 lbs.	325° F	180° F	12-16
	Chicken	3 to 4 lbs.	350-375° F	180° F	12-16

^{*} Stuffed turkey requires additional roasting time. Shield legs and breast with foil to prevent overbrowning and dying of the skin.

TEMPERATURE PROBE



For many foods, especially roasts and poultry, testing the internal temperature is the best method to insure properly cooked food. The Temperature Probe gets the exact temperature you desire without having to guess. This feature can be used with Bake, Convection Bake, Convection Roast and Perfect Turkey cooking modes. The oven can be programmed for Probe at any temperature between 130°F to 210°F with a default temperature of 170°F. This unit is equipped with one temperature probe entry in the upper oven only.

IMPORTANT:

- 1. Use only the probe supplied with your appliance; any other may result in damage to the probe or the appliance.
- 2. Handle the Temperature Probe carefully when inserting and removing it from the food and outlet.
- 3. Do not use tongs to pull the cable when inserting or removing the Probe. It could damage the Probe.
- 4. Defrost your food completely before inserting the Probe to avoid breaking it.
- 5. Never leave or store the Temperature Probe inside the oven when not in use.
- 6. To prevent the possibility of burns, carefully unplug the Temperature Probe using hot pads.

Proper Temperature Probe Placement:

- 1. Always insert the probe so that the tip rests in the center of the thickest part of the meat. Do not allow probe to touch bone, fat, gristle or pan.
- 2. For bone-in ham or lamb, insert the Probe into the center of the lowest large muscle or joint. For dishes such as meat loaf or casseroles, insert the Probe into the center of the food. When cooking fish, insert the Probe from just above the gill into the meatiest area, parallel to the backbone.

Figure 1

3. For whole poultry (chicken, turkey, etc.), insert the probe into the thickest part of the inner thigh from below and parallel to the leg (see figure 1).

Setting the Oven when using the Temperature Probe:

- 1. Insert the Temperature Probe into the food (see Proper Temperature Probe Placement above).
- 2. Plug the Temperature Probe into its outlet in the oven. (The outlet is located on the top left hand side of the cavity wall, near front of the oven). Always insert the probe into a cool oven. Make sure it is pushed all the way into the outlet. Close the oven door.
- 3. Start an available cooking mode by pressing **UPPER OVEN** OVEN followed by either **BAKE** CONVECTION BAKE or CONVECTION ROAST.
- 4. A target temperature must be set to trigger the buzzer when the food reaches the set temperature. Press **COOK OPTIONS** of to bring up the cook options items and press **PROBE** pad to enter the temperature. Adjust temperature to the desired setting using the numeric pads or just press **START** to use the default target temperature of 170°F. The pads h or lo can also be pressed to raise or lower the temperature. The target temperature setting will be accepted after the **START** pad is pressed.
- 5. At any time during the cooking, the **PROBE** ?? pad can be pressed once to display the actual meat temperature or pressed twice to display the target temperature. When on the target temperature display, a new temperature can be entered. After 5-8 seconds, the display will go back to showing the oven temperature.
- 6. When the food reach the target temperature, the oven will go into a **KEEP WARM** mode until you press **CANCEL** (7).

The probe can be damaged by very high temperature. To protect the probe against this damage, the oven control will not allow you to start a self-clean, broil or convection broil while the probe is connected.

MULTI STAGE

This feature enables you to perform sequential cooking at the touch of a button. Its purpose is to program a queue of up to three cooking modes with individual cooking time and temperatures in a sequence. This feature can be used with most cooking modes; Baking, Broiling, Convection Baking, Convection Roasting, Convection Broiling, Keep Warm and Bread Proof. A Cook Time can be programmed with your cooking mode and then queued. No Auto-Suggest default

	·	•	•
1.	Arrange interior oven racks and place food.		
2	Soloct oven by pressing LIPPED OVEN UPPER		

can sta	sperature is provided with this feature. Any stage programmed with Broil or Convection Broi snot last longer than 10 minutes. A proper cook time and a set temperature are required for every ge programming. At least two stages must be programmed before a Multi-Stage cooking eration starts.
To 1. 2.	set a Multi Stage sequence (Timed Convection Bake, Timed Broil, Keep Warm): Arrange interior oven racks and place food. Select oven by pressing UPPER OVEN OVEN
3.	Press MULTI STAGE 32. Stage 1
4.	Press CONVECTION BAKE . " 000 " will flash in the display prompting to enter a temperature.
5.	Enter a temperature using the numeric pads ① to ⑨.
6.	Press START ①. " 00:00 " will start flashing in the display prompting to enter a cook time
7.	Enter a cook time using the numeric pads ① to ⑨.
8.	Press START ①. The Multi-Stage indicator will now display the 2nd stage. Stage 2
9.	Press BROIL " 000 " will start flashing in the display prompting to enter a temperature
10.	Enter a temperature using the numeric pads ① to ⑨.
11.	Press START ①. " 00:00 " will start flashing in the display prompting to enter a cook time
12.	Enter a cook time using the numeric pads ① to ⑨.
13.	Press START ①. The Multi-Stage indicator will now display the 3rd stage. If a third stage
	is not needed, press START a second time. This will start the cooking sequence. Stage 3
14.	Press KEEP WARM . "000" will start flashing in the display prompting to enter a temperature.
15.	Enter a temperature using the numeric pads ① to ⑨.
16.	Press START ①. " 00:00 " will start flashing in the display prompting to enter a cook time
17.	Enter a cook time using the numeric pads ① to ⑨.
18.	Press START twice. The cooking sequence will begin. ———————————————————————————————————
20.	At the end of the sequence, the display will show "End" and a chime will sound.
21.	Remove food.
22	Press CANCEL (7) to stop or cancel the Multi-Stage seguence at any time

MULTI STAGE (CONTINUED)

1₂2

To review and edit a Multi Stage sequence:

Once the first and second stages have been programmed, the control displays a Review Screen. During this mode, the temperature display is cleared, the stage numbers are lit and the numeric pads corresponding to the programmed stages are lit.

To review a programmed stage cooking mode, press the corresponding numeric pad. The temperature and cook time pads will light up and the control will display the programmed values.

To edit a programmed stage cooking mode being reviewed, press CANCEL \bigcirc . This will bring you back to the programming steps explained in the previous page. The third stage cannot be edited but can be deleted by pressing CANCEL \bigcirc on the review screen. To return to the review screen from the programming screen, at any time press MULTI STAGE $\frac{1}{3}$ 2.

To begin the cooking sequence from the review screen, simply press START .

USER PREFERENCES

The User Preferences menu includes all user defined options. This feature enables you to control the various options of the electronic controls. This menu features the Time of Day, Celsius or Fahrenheit display mode, Continuous Bake or 12 Hour Energy Saving modes, Clock display or No-Clock display, 12 Hours Time of Day or 24 Hours Time of Day, Audio Control, and Adjusting the oven temperature. The User Preferences menu is only available when the oven is not being used (not cooking).

To browse through the User Preferences menu:

- 1. Press **USER PREF** to bring up the User Preferences menu.
- 2. Press **USER PREF** again to browse through the menu pages.
- 3. Press $_{\rm hi}^{^+}$ or $_{\rm lo}^{^-}$ to toggle between the available options.
- 4. Press **START** () while the chosen option is on display to change.
- 5. Press **CANCEL** \bigcirc when finished to get back to the standard oven display.

User Preferences menu items:

- CLO 12:00; Setting the clock.
- CLO on; Clock on/off.
- CLO 12hr; 12/24 hour time of day display. E S on ; 12 hour Energy Saving on/off.
- **UPO**; Adjusting oven temperature.
- F-C F; Fahrenheit / Celcius display.
- AUd; Audio on/off and volume.
- rSt : Reset to default factory settings.

SETTING THE CLOCK - TIME OF DAY

The clock may be set for 12 or 24 hour time of day operation (see advanced settings section). The clock has been preset at the factory for the 12 hour operation. When the range is first plugged in, or when the power supply to the range has been interrupted, the display will show "CLO 12:00". The clock must be set before the oven can be used.

When power to the unit has been interrupted, "12:00" appears and flashes in the display. To set the Clock in this case, skip step 1 in the example below and follow steps 2 and 3.

To set the clock (example for 1:30):

- 1. Press USER PREF Duntil you get to the CLO 12:00 menu page.
- 2. Press (1)(3)(0) pads to set the time of day to 1:30. The pads $\frac{1}{h}$ or $\frac{1}{h}$ can also be pressed to raise or lower the actual time displayed.
- 3. Press **START** (1) to accept the changes and go back to user preferences menu display.

USER PREFERENCES (CONTINUED)



SETTING CLOCK DISPLAY — ON OR OFF

The oven control can be programmed to display the time of day or not. The oven has been preset at the factory to display the time of day.

Changing clock display between ON and OFF:

- 1. Press **USER PREF** until you get to the **CLO on** menu page.
- 2. Press $_{hi}^{+}$ or $_{lo}^{-}$ to toggle between displaying or hiding the clock.
- 3. Press **START** (1) to accept the changes and go back to user preferences menu display.

SETTING TIME OF DAY DISPLAY — 12 OR 24 HOURS

The oven control can be programmed to display time of day in 12 hours or 24 hours mode. The oven has been preset at the factory to display in 12 hours mode.

Changing between 12 or 24 hour time of day display:

- 1. Press USER PREF until you get to the CLO 12hr menu page.
- 2 Press $_{hi}^+$ or $_{lo}^-$ to toggle the display of the clock in 12 or 24 hours.
- 3. Press START () to accept the changes and go back to user preferences menu display.
- 4. Remember to set your clock after changing the time of day display mode.

ADJUSTING OVEN TEMPERATURE

The temperature in the oven has been pre-set at the factory. When first using the oven, be sure to follow recipe times and temperatures. If you think the oven is too hot or too cool, the temperature in the oven can be adjusted. Before adjusting, test a recipe by using a temperature setting that is higher or lower than the recommended temperature. The baking results should help you to decide how much of an adjustment is needed. Each oven can be individually adjusted.

To adjust the oven temperature:

- 1. Press **USER PREFERENCES** until you get to the **UPO** menu page.
- 2. Enter the temperature by pressing the $_{hi}^{+}$ or $_{lo}^{-}$ pads. The temperature can only be adjusted by $\pm 35^{\circ}$ F.
- 3. Press **START** to accept the changes and go back to user preferences menu display.

Electronic Control Settings

USER PREFERENCES (CONTINUED)

SETTING TEMPERATURE DISPLAY — FAHRENHEIT OR CELSIUS

The oven control can be programmed to display temperatures in Fahrenheit or Celsius. The oven has been preset at the factory to display in Fahrenheit.

To change display from Fahrenheit to Celsius or Celsius to Fahrenheit:

- 1. Press **USER PREF** until you get to the **F-C F** menu page.
- 2. Press ⁺_{bi} or ⁻_{lo} to toggle between the °C and °F display options.
- 3. Press **START** (1) to accept the changes and go back to user preferences menu display.

AUDIO CONTROL

The Audio Control feature allows the oven control to be operated without sounds or beeps whenever necessary. If desired the control can be programmed for silent operation and later returned to operating with all the default sounds and beeps. The volume of the beeps can also be adjusted.

To change the audio mode or audio volume:

- 1. Press **USER PREF** until you get to the **AUd** menu page.
- 2. Press $_{hi}^{+}$ or $_{lo}^{-}$ to toggle between the available volume settings. **AUd 5** for the highest volume setting to **AUd 1** for the lowest volume. **AUd OFF** to disable the beeps.
- 3. Press **START** to accept the changes and go back to user preferences menu display.

SETTING CONTINUOUS BAKE OR 12 HOUR ENERGY SAVING

The oven control has a factory preset built-in 12 Hour Energy Saving feature that will shut off the oven if the oven control is left on for more than 11 hours and 59 minutes. The oven can be programmed to override this feature for Continuous Baking.

Changing between 12 hour energy saving and continuous bake:

- 1. Press **USER PREF** until you get to the **E S** menu page.
- 2. Press $\frac{1}{h}$ or $\frac{1}{h}$ to toggle the energy saving setting on and off.
- 3. Press **START** () to accept the changes and go back to user preferences menu display.

RE-SETTING TO DEFAULT FACTORY SETTINGS

The oven control can be set to return to its original factory settings. This includes: Setting the Clock ON/OFF to ON, Setting the clock display mode to 12h, Display mode to Fahrenheit, Setting the oven temperature adjustment to zero, Setting audio level to 5 and Enabling the 12h energy saving mode. Reseting the control also erase the My Favorite recipes.

To reset the oven control to its original settings:

- 1. Press **USER PREF** until you get to the **rSt no** menu page.
- 2. Press hi or lo to select **YES**.
- 3. Press **START** \bigcirc to reset to default factory settings.



MY FAVORITES







The Favorites settings allows you to save your most frequently used or most complex cooking sequences. This feature will save the cooking mode, the target temperature and the cooktime (if any). The oven can recall up to three cooking sequences from its internal memory, which are easily accessible from a one touch button. These functions can be used with all cooking modes and features.

To save a Favorite (example is a 450°F Bake for 30 minutes):

- Saving a Favorite can only be done for an oven which is currently in operation.
- 1. Select oven by pressing **UPPER OVEN** OVEN.
- 3. Enter temperature needed; (4)(5)(0).
- 4. Press **COOK OPTIONS** \bigodot to bring up the cook options items.
- 5. Press COOK TIME (1).
- 6. Enter time needed; (3)(0).
- 7. Press **START** 🗘.
- 8. Press and hold for 3 seconds any **MY FAVORITE** \bigcirc pad. Notice that the red indicator above the key will light up.

To recall a Favorite:

- Recalling a Favorite can only be done for an oven which is not currently in operation.
- 1. Select oven by pressing **UPPER OVEN** OVEN.
- 2. Press any **MY FAVORITE** \bigcirc pad which is currently lighted up.
- 3. Press **START** ①.

To overwrite a Favorite:

 To overwrite a My Favorite simply start a new cooking sequence and save it into the same My Favorite location (1, 2 or 3) for the selected oven as shown in example above. The new My Favorite settings will overwrite the old ones.

To delete a Favorite:

- 1. Select oven by pressing **UPPER OVEN** OVEN OVEN
- 2. Press the currently lighted up MY FAVORITE () pad you wish to delete for 3 seconds.

SABBATH FEATURE

(FOR USE ON THE JEWISH SABBATH & HOLIDAYS)

The **HI** ⁺_{hi} and **LO** ⁻_{lo} pads are used to set the Sabbath feature. The Sabbath feature may only be used with the **BAKE** pad. The oven temperature may be set higher or lower after setting the Sabbath feature (the oven temperature adjustment feature should be used only during Jewish Holidays), however the display will not visibly show or provide any audible tones indicating whether the change occurred correctly. Once the oven is properly set using Bake with the Sabbath feature active, the oven will remain continuously ON until cancelled. This will override the factory preset 12-Hour Energy Saving feature.

If the oven light will be needed during the Sabbath, press **OVEN LIGHT** Ω before activating the Sabbath feature. Once the oven light is turned ON and the Sabbath feature is active, the oven light will remain ON until the Sabbath feature is turned OFF. If the oven light needs to be OFF, be sure to turn the oven light OFF before activating the Sabbath feature.

IMPORTANT NOTES: It is not advised to attempt to activate any other program feature other than **BAKE** while the Sabbath feature is active. ONLY the following key pads will function after setting the Sabbath feature; ① to ②, **BAKE**, **START**, **CANCEL**, **HI**, and **LO**. **ALL OTHER KEYPADS** will not function once the Sabbath feature is properly activated.

To Program the Upper Oven to Begin Baking Immediately & Activate the Sabbath feature (example: baking at 350°F)

- 1. Place the food in the oven.
- 2. Select oven by pressing either **UPPER OVEN** OVEN OVEN OVEN.
- 3. Press BAKE
- 4. If you desire to set the oven control for a **COOK TIME** (4) do so at this time. If not, skip this step and continue to step 5. Refer to their section for complete instructions. Remember the oven will shut down after using **COOK TIME** (4) and therefore may only be used once during the Sabbath/Jewish Holidays.
- 5. Press **START** ①.
- 6. The oven will turn ON and begin heating immediately.
- 7. Press and hold both the **HI** $_{hi}^{+}$ and **LO** $_{lo}^{-}$ pads for at least 3 seconds. **SAb** will appear in the oven display and **Sb** in the cooktop displays. Once SAb appears in the display the oven control will no longer beep or display any further changes and the oven is properly set for the Sabbath feature.



SABBATH FEATURE (CONTINUED)



Note: You may change the oven temperature once baking has started. Press UPPER OVEN UPPER, BAKE, the numeric key pads for the temperature you want (example for 425°F press 4), (2), (5)) and then press START TWICE (for Jewish Holidays only). Remember that the oven control will no longer beep or display any further changes once the oven is set for the Sabbath feature.

8. The oven may be turned OFF at any time by pressing **CANCEL** pad (this will turn the oven OFF only). To turn OFF the Sabbath feature press and hold both the **HI** $_{hi}^{+}$ and **LO** $_{lo}^{-}$ pads for at least 3 seconds. **SAb** will disappear from the display.

Should you experience a power failure or interruption, the oven will shut off. When power is returned the oven will not turn back on automatically. **SF** (Sabbath Failure) will be displayed in the oven control display. The oven will remember that it is set for the Sabbath and the food may be safely removed from the oven while still in the Sabbath feature, however the oven cannot be turned back on until after the Sabbath. After the Sabbath observance turn OFF the

Sabbath feature. Press and hold both the HI_{hi}^+ and LO_{lo}^- pads for at least 3 seconds. **SAb** will disappear from the display and the oven may be used with all normal functions. For further assistance, guidelines for proper usage, and a complete list of models with the Sabbath feature, please visit the web at http://www.star-k.org.

USING THE SELF-CLEAN FEATURE

Adhere to the Following Cleaning Precautions:

- Allow the oven to cool before cleaning.
- Wear rubber gloves when cleaning any exterior parts of the oven manually.

During the self-cleaning cycle, the outside of the wall oven can become very hot to the touch. DO NOT leave small children unattended near the appliance.

Before cleaning any part of the oven, be sure the oven is turned off or else push **CANCEL** \bigcirc pad. Wait until the oven is cool.

DO NOT use commercial oven cleaners or oven protective coatings in or around any part of the self-cleaning oven. DO NOT clean the oven door gasket. The gasket on the oven door is essential for a good seal. Care should be taken not to rub, damage or move the gasket. DO NOT use any cleaning materials on the gasket. Doing so could damage it. DO NOT use aluminum foil to line the oven bottom. This may affect cooking or foil could melt and damage the oven surface.

Preparing the Oven for Self-Cleaning:

- Remove any excess spillovers in the oven cavity before starting the self-cleaning cycle. To clean, use hot soapy water and a cloth. Large spillovers can cause smoke or a fire when subjected to high temperatures. DO NOT allow food spills with a high sugar or acid content (such as tomatoes, sauerkraut, fruit juices or pie filling) to remain on the surface as they may leave a dull spot even after cleaning.
- 2. Clean any soil from the oven frame and the door liner (see illustration). These areas heat sufficiently during a self-clean to burn soil on. Clean with hot soapy water.
- 3. Remove the broiler pan and insert, all utensils and any foil. These items can not withstand high cleaning temperatures.
- 4. Oven racks and oven rack supports must be removed. If they are not removed the self-cleaning cycle can not start and

Remove Racks will appear in the display indicating that you must remove the racks and racks supports. When the cycle has finished and the door can be opened replace the oven rack supports and oven racks.

ACAUTION The health of some birds is extremely sensitive to the fumes given off during the self-clean cycle of any wall oven. Move birds to another well ventilated room.





STARTING SELF-CLEAN CYCLE

A self-cleaning oven cleans itself with high temperatures (well above cooking temperatures) which eliminate soil completely or reduce it to a fine powdered ash you can whisk away with damp cloth. If you are planning to use the oven directly after a self-clean cycle remember to allow time for the oven to cool down and the oven door to unlock. This normally takes about one hour.

To set the controls for a Self-Cleaning cycle:

- 1. Remove the oven racks and the racks supports.
- 2. Be sure the clock is set with the correct time of day and the oven door is closed.
- 3. Select oven by pressing UPPER OVEN OVEN OVEN
- 4. Press CLEAN 🔆.
- 5. Press LITE for a 2 hour self-clean, or press MEDIUM • for 3 hours, or press HEAVY • • for 4 hours.
- 6. Press **START** ⟨I⟩. The "**DOOR** ☐ " icon will flash.

Note: Allow about 15 seconds for the oven door lock to close.

To set the controls for a delayed Self-Cleaning cycle:

- Follow the instructions above.
- 2. Press **COOK OPTIONS** (v) to bring up the cook options items.
- 3. Press **END TIME** . The time of day numbers will blink in the display.
- 4. Enter time of day needed for the end of the cycle (example for "6:00"; 600).
- Press START ().

When the Self-Clean Cycle is Completed:

- 1. The time of day and "DOOR 🗊 " will remain ON.
- The display will show an "Hot" message while the oven is still too hot to open door.

Stopping or Interrupting a Self-Cleaning Cycle:

If it becomes necessary to stop or interrupt a self-cleaning cycle due to excessive smoke in the oven:

- 1. Press CANCEL ().
- 2. Once the oven has cooled down for approximately 1 HOUR and the "**DOOR** ☐ " icon is no longer displayed,the oven door can then be opened.

A WARNING During the self-cleaning cycle, the outside of the wall oven can become very hot to the touch. **DO NOT** leave small children unattended near the appliance; they may be burned if they touch the hot oven door surfaces.

A CAUTION DO NOT force the oven door open. This can damage the automatic door locking system. Use care when opening the oven door after the self-cleaning cycle. Stand to the side of the oven when opening the door to allow hot air or steam to escape. The oven may still be VERY HOT.

GENERAL CLEANING

Cleaning Various Parts of Your appliance

Before cleaning any part of the appliance, be sure all controls are turned OFF and the appliance is COOL. REMOVE SPILLOVERS AND HEAVY SOILING AS SOON AS POSSIBLE. REGULAR CLEANINGS WILL REDUCE THE NUMBER OF MAJOR CLEANINGS LATER



Surfaces	How to Clean	
Glass, Painted and Plastic Body Parts and Decorative Trim	For general cleaning, use hot, soapy water and a cloth. For more difficult soils and built-up grease, apply a liquid detergent directly onto the soil. Leave on soil for 30 to 60 minutes. Rinse with a damp cloth and dry. DO NOT use abrasive cleaners on any of these materials; they can scratch.	
Control Panel	Before cleaning the control panel, turn all controls to OFF. Lightly spray the control panel with a liquid cleaner. Wipe with a soft cloth or paper towel. DO NOT use abrasive cleaners or scouring pads. These can permanently damage the control panel surface.	
Porcelain Enamel Broiler Pan and Grid, Griddle	Gentle scouring with a soapy scouring pad will remove most spots. Rinse with a 1:1 solution of clear water and ammonia. <i>If necessary</i> , cover difficult spots with an ammonia-soaked paper towel for 30 to 40 minutes. Rinse with clean water and a damp cloth, and then scrub with a soap-filled scouring pad. Rinse and wipe dry with a clean cloth. Remove all cleaners or the porcelain may become damaged during future heating.	
Stainless Steel, Chrome Decorative Trim, Oven Racks, Oven Racks Support	Clean with hot, soapy water and a dishcloth. Rinse with clean water and a cloth. Cover stubborn spots with an ammonia-soaked paper towel for 30 to 40 minutes. Rinse. Cleaners made especially for stainless steel are recommended. Be sure to rinse the cleaners as bluish stains may occur during heating and cannot be removed.	
Oven Racks	Oven racks and oven rack supports must be removed from the oven during the self-clean cycle for cleaning. If they are not removed, the self-clean cycle will not start. Clean them as described above.	
Oven Door	To clean oven door, wash with hot, soapy water and a clean cloth. DO NOT immerse the door in water or clean the oven door gasket.	
Oven Door Gasket	The oven gasket located on the inner frame of the door and visible when the door is opened is essential for a good seal. Care should be taken not to rub, damage or remove the gasket.	
Lower Oven	To remove burned-on fat on oven walls, moisten soiled parts with household ammonia, using a wet cloth. Complete cleaning with a damp cloth and use a fine steel wool scouring agent if necessary.	

44 Care & Cleaning


CARE AND CLEANING OF STAINLESS STEEL

Special care and cleaning are **required** for maintaining the appearance of stainless parts. Please refer to the table provided at the beginning of the **General Care & Cleaning** section in this Use & Care Manual.


TO REMOVE AND REPLACE OVEN DOOR

- 1. Open the door to the fully opened position.
- 2. Pull up the lock located on each hinge support toward front of range. You may have to apply a little upward pressure on the lock to pull it up.
- 3. Grasp the door by the sides, pull the bottom of the door up and toward you to disengage the hinge supports.
 - Keep pulling the bottom of the door toward you while rotating the top of the door toward the appliance to completely disengage the hinge levers.
- 4. Proceed in reverse to re-install the door. Make sure the hinge supports are fully engaged before unlocking the hinge levers.

Removal of the Oven Door



Lock in normal position



Lock engaged for door removal



HINGE SLOT - Door removed from the appliance

SPECIAL DOOR CARE INSTRUCTIONS

Most oven doors contain glass that can break.

Read the following recommendations:

- 1. Do not close the oven door until all the oven racks are fully in place.
- 2. Do not hit the glass with pots, pans, or any other object.
- 3. Scratching, hitting, jarring or stressing the glass may weaken its structure causing an increased risk of breakage at a later time.

OVEN LIGHT

An interior oven light will turn on automatically when the oven door is opened. The oven light may be turned on when the door is closed by using the oven light switch located on the control panel.


The lamp is covered with a glass shield. The glass shield can be remove to be cleaned manually or to change the oven light.

THIS GLASS SHIELD MUST BE IN PLACE WHENEVER THE OVEN IS IN USE.

To replace the light bulb:

CAUTION: BE SURE THE OVEN IS COOL.

- 1. Turn the power off at the main source.
- 2. Wear a leather-faced glove for protection against possible broken glass.
- 3. To remove the glass shield, pull the back side of the shield toward the inside of the oven in a manner to lift it up from the oven side.
- 4. The glass shield should come out easily by pushing a little toward front of the wall oven.
- 5. Replace halogen light appliance bulb taking care to not touch the bulb. Touching the halogen bulb with bare fingers can damage it and also burn it.
- 6. To replace glass shield, proceed in reverse.




BROILER PAN CLEANING TIPS


To make cleaning easier, line the bottom of the broiler pan with aluminum foil. DO NOT cover the broiler grid with foil.

To prevent grease from baking on, remove the broiler pan from the oven as soon as cooking is completed. Use hot pads because the broiler pan is extremely hot. Pour off grease. Soak the pan in HOT, soapy water.

Clean the broiler pan as soon as possible after each use. If necessary, use soap-filled steel wool pads. Heavy scouring may scratch the grid.



CLEANING THE BURNER GRATES, BURNER CAPS AND BURNER HEADS



The Grates, Burner Caps and the Large 18k Burner Head should be routinely cleaned. Keeping the burner ports clean will prevent improper ignition and an uneven flame. If needed, the fixed burners should be cleaned in place with an humid cloth (do not spraw water on them).

Refer to the following instructions:

To Remove and Replace the Surface Burner Grate, Surface Burner Cap and Surface Burner Head -Remove in the following order; (1st) Surface Burner Grate, (2nd) Surface Burner Cap, (3rd) Surface Burner Head (See Figure 1).

Reverse the procedure above to replace the Surface Burner Cap, Surface Burner Head and Surface Burner Grate. Do not remove any burner parts from the cooktop until the burner parts have completely cooled and are safe to handle. Do not operate the surface burners without the Surface Burner Heads, Surface Burner Caps and Surface Burner Grates properly in place.

To Clean the Burner Caps, Burner Heads and Burner Grates - Use a soap-filled scouring pad or a mild abrasive cleaner to clean the surface burner caps and surface burner heads. The Grates are designed to be Dishwasher safe for cleaning. The ports (or slots) around the burner heads must be routinely cleaned. If residue still remains in these ports, use a small-gauge wire or needle to clean the slots or holes being careful not to damage the electrode. For proper flow of gas and ignition of the burner—DO NOT ALLOW SPILLS, FOOD, CLEANING AGENTS OR ANY OTHER MATERIAL TO ENTER THE GAS ORIFICE HOLDER OPENING. ALWAYS make sure that the surface burner cap, the surface burner head and the surface burner grate are properly in place whenever a surface burner is in use.







Surface Burner Grate

Surface Burner Caps

THE COOKTOP IS NOT REMOVABLE. Do not attempt to remove or lift the cooktop.

A CAUTION

- Use caution when replacing the burner head so the electrode is not damaged. A damaged electrode may cause a delayed ignition or prevent the burner from igniting
- Any additions, changes or conversions required in order for this appliance to perform satisfactorily must be made by a qualified service technician.

PORCELAIN ENAMEL COOKTOP CLEANING INSTRUCTIONS

MARNING

Do not use a cooktop cleaner on a hot cooktop. The fumes can be hazardous to your health, and can chemically damage the cooking surface.

A CAUTION

Before cleaning the surface cooktop, be sure the controls are turned to OFF and the cooktop is cool.

DO NOT use commercial oven cleaners on the **exterior** surfaces including rangetop and door frame.

Correct and consistent cleaning is essential to maintaining your porcelain enamel cooktop. If food spills and grease spatters are not removed, they may burn onto the surface of the cooktop and cause permanent discoloration.

Daily Cleaning

For normal soil:

- 1. Allow cooktop surface to cool.
- 2. Wipe off spills and spatters using a clean paper towel or a clean cloth with warm, soapy water.
- 3. If needed, use mild household cleaners or a soap-filled steel wool pad.
- 4. Be sure to rinse off all cleaning solutions or the porcelain may become damaged during future heating.

For heavy, burned-on soil:

- 1. Allow cooktop surface to cool.
- 2. Use a soap filled scouring pad with warm water or cover heavily soiled spots with a solution of clear water and ammonia. Scour gently. Rinse and wipe dry with a clean cloth.

Solutions to Common Problems

Baking Problems

For best cooking results pre-heat the oven when baking cookies, breads, cakes, pies or pastries, etc. There is no need to preheat the oven for roasting meats or baking casseroles. The cooking times and temperatures needed to bake a product may vary slightly from your previous appliance.

Baking Problems and Solutions Chart			
BakingProblems	Causes	Solutions	
Cookies and biscuits burn on the bottom.	 Cookies and biscuits put into the oven before the preheating time is completed. Oven rack overcrowded or rack position too low. Dark pan absorbs heat too fast. 	 Allow oven to preheat to the selected temperature before placing food in oven. Choose pan sizes that will permit 5.1 cm to 10.2 cm (2" to 4") of air space on all sides when placed in the oven. Use a medium-weight aluminum baking sheet. 	
Cakes too dark on top or bottom.	 Cakes put into the oven before preheating time is completed. Rack position too high or low. Oven too hot. 	 Allow oven to preheat to the selected temperature before placing food in the oven. Use proper rack position for baking needs. Set oven temperature 25°F/12°C lower than recommended. 	
Cakes not done in the center.	 Oven too hot. Incorrect pan size. Pan not centered in oven. 	 Set oven temperature 25°F/12°C lower than recommended. Use pan size suggested in recipe. Use proper rack position and place pan so there is 5.1 cm to 10.2 cm (2" to 4") of space on all sides of pan. 	
Cakes not level.	 Range not level. Pan too close to oven wall or rack overcrowded. Pan warped. 	 Place a marked glass measuring cup filled with water on the center of the oven rack. If the water level is uneven, refer to the installation instructions for leveling the range. Be sure to allow 5.1 cm to 10.2 cm (2" to 4") of clearance on all sides of each pan in the oven. Do not use pans that are dented or warped. 	
Foods not done when cooking time is up.	 Oven too cool. Oven overcrowded. Oven door opened too frequently. 	 Set oven temperature 25°F/12°C higher than suggested and bake for the recommended time. Be sure to remove all pans from the oven except the ones to be used for baking. Open oven door only after shortest recommended baking time. 	

Solutions to Common Problems

IMPORTANT

Before calling for service, review this list. It may save you both time and expense. This list includes common experiences that are not the result of defective workmanship or material in your cooktop.

OVEN CONTROL BEEPS AND DISPLAYS AN "F" ERROR CODE

• Electronic control has detected a fault condition. Push **CANCEL pad** to clear the display and stop the display from beeping. Reprogram the oven. If a fault reoccurs, record the fault number, push the **CANCEL pad** and contact an authorized servicer.

INSTALLATION

- Place oven rack in center of oven. Place a level on the oven rack. Contact installing agent if rack and cabinet cutout flooring are not level.
- Kitchen cabinet misalignment may make range appear to be not level. Be sure cabinets are square and level. Contact cabinet maker to correct problem.

ENTIRE RANGE DOES NOT OPERATE

- When the range is first plugged in, or when the power supply to the oven has been interrupted, the display will flash. The range cannot be programmed until the clock is set.
- Be sure electrical cord is securely connected into the electrical junction box.
- Cord/plug is not installed and/or connected. Cord is not supplied with range. Contact your dealer, installing agent or authorized servicer.
- Service wiring not complete. Contact your dealer, installing agent or authorized servicer.
- Power outage. Check house lights to be sure. Call your local electric company.
- · Short in cord/plug. Replace cord/plug.
- · Controls are not set properly. See instructions to set the controls.
- House fuse has blown or circuit breaker has tripped immediately following installation.
- House fuse may not be fully engaged. Check fuse and screw or engage circuit breaker securely.

OVEN LIGHT DOES NOT WORK

 Burned-out or loose bulb. Follow the instructions under Oven Light to replace or tighten the bulb.

50 Solutions to Common Problems

SELF-CLEANING CYCLE DOES NOT WORK

- Make sure the oven door is closed.
- Make sure you have removed the oven racks and the oven rack supports from the oven.
- Controls not set properly. Follow instructions under "Using the Self-Clean Feature".

OVEN SMOKES EXCESSIVELY DURING BROILING

- Meat too close to the broiler element. Reposition the rack to provide more clearance between the meat and the broiler. Preheat broil element for quick searing operation.
- Meat not properly prepared. Remove excess fat from meat. Cut remaining fatty edges to prevent curling, but do not cut into the lean.
- Grid on broiler pan wrong side-up. Grease does not drain into broiler pan. Always place the grid on the broiler pan with the ribs up and the slots down to allow grease to drip into the pan.
- Broiler pan used without grid or grid cover with aluminum foil. DO NOT use the broiler pan without the grid or cover the grid with aluminum foil.
- Oven needs to be cleaned. Grease has built up on oven surfaces. Regular cleaning is necessary when broiling frequently. Grease or food spatters cause excessive smoking.

SOIL NOT COMPLETELY REMOVED AFTER SELF-CLEANING CYCLE IS COMPLETED

- Failure to clean bottom, from top of oven, frame of oven or door area outside oven seal. These areas are not in the self-cleaning area, but get hot enough to burn on residue. Clean these areas before the self-cleaning cycle is started. Burned on residue can be cleaned with a stiff nylon brush and water or a nylon scrubber. Be careful not to damage the oven gasket.
- Excessive spillovers in oven. Set the self-clean cycle for longer cleaning time.

POOR COOKING RESULTS

- Many factors affect baking results. See Baking for hints, causes and corrections.
 See Adjusting Oven Temperature.
- Many factors affect cooking results. Adjust the recipe's recommended power levels or cooking times.
- Cookware is too lightweight or warped. Use heavier quality cookware so foods being prepared may cook more evenly.

FLAMES INSIDE OVEN OR SMOKE FROM VENT

 Excessive spillovers in oven. This is normal, especially for high oven temperatures, pie spillovers or for large amounts of grease on bottom of oven. Wipe up excessive spillovers.

SURFACE BURNERS DO NOT LIGHT

- Surface Control knob has not been completely turned to LITE. Push in and turn the Surface Control knob to LITE until burner ignites and then turn control knob to desired flame size.
- Be sure gas supply valve is open.
- Burner ports are clogged. Clean burners. See Cleaning the Burner Grates, Burner Caps, Burner Heads in General Care & Cleaning section. With the burner off, clean ports with a small-gauge wire or needle.
- Power cord is disconnected from outlet (Electric Ignition Models only). Be sure cord is securely plugged into the outlet.
- Electrical power outage (electric ignition models only). Burners can be lit manually. See **Setting Surface Controls** in this Use and Care Guide.

BURNER FLAME ONLY LIGHTS HALF WAY AROUND BURNER

- Burner ports are clogged. With the burner off, clean ports by using a small-gauge wire or needle.
- Moisture is present after cleaning. Lightly fan the flame and allow burner to operate until flame is full. Dry the burners thoroughly following instructions in the General Cleaning section.

FOOD NOT HEATING EVENLY

- Improper cookware. Select flat-bottomed cookware of a proper size to fit element.
- Incorrect control setting. Raise or lower setting until proper amount of heat is obtained.

BURNER FLAME IS ORANGE

- Dust particles in main line. Allow the burner to operate a few minutes until flame turns blue.
- In coastal areas, a slightly orange flame is unavoidable due to salt air.Ceramic-Glass Cooktop section in this Owner's Guide.
- Cookware with rough bottom has been used. Use flat-bottomed, smooth utensils. See Selecting Surface Cooking Utensils in this Owner's Guide.

52 Warranty Information

Your appliance is covered by a one year limited warranty. For one year from your original date of purchase, Electrolux will repair or replace any parts of this appliance that prove to be defective in materials or workmanship when such appliance is installed, used, and maintained in accordance with the provided instructions. In addition, the glass cooktop or radiant surface element of your appliance (excluding built-in and free-standing range appliances) is covered by a two through five year limited warranty. During the 2nd through 5th years from your original date of purchase, Electrolux will provide a replacement glass cooktop or radiant surface element for your appliance which has proven to be defective in materials or workmanship when such appliance is installed, used, and maintained in accordance with the provided instructions.

Exclusions

This warranty does not cover the following:

- 1. Products with original serial numbers that have been removed, altered or cannot be readily determined.
- 2. Product that has been transferred from its original owner to another party or removed outside the USA or Canada.
- 3. Rust on the interior or exterior of the unit.
- 4. Products purchased "as-is" are not covered by this warranty.
- 5. Food loss due to any refrigerator or freezer failures.
- 6. Products used in a commercial setting.
- 7. Service calls which do not involve malfunction or defects in materials or workmanship, or for appliances not in ordinary household use or used other than in accordance with the provided instructions.
- 8. Service calls to correct the installation of your appliance or to instruct you how to use your appliance.
- 9. Expenses for making the appliance accessible for servicing, such as removal of trim, cupboards, shelves, etc., which are not a part of the appliance when it is shipped from the factory.
- 10. Service calls to repair or replace appliance light bulbs, air filters, water filters, other consumables, or knobs, handles, or other cosmetic parts.
- 11. Labor or in-home service costs during the additional limited warranty periods beyond the first year from your original date of purchase.
- 12. Pickup and delivery costs; your appliance is designed to be repaired in the home.
- 13. Surcharges including, but not limited to, any after hour, weekend, or holiday service calls, tolls, ferry trip charges, or mileage expense for service calls to remote areas, including the state of Alaska.
- 14. Damages to the finish of appliance or home incurred during transportation or installation, including but not limited to floors, cabinets, walls, etc.
- 15. Damages caused by: services performed by unauthorized service companies; use of parts other than genuine Electrolux parts or parts obtained from persons other than authorized service companies; or external causes such as abuse, misuse, inadequate power supply, accidents, fires, or acts of God.

DISCLAIMER OF IMPLIED WARRANTIES; LIMITATION OF REMEDIES

CUSTOMER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE REPAIR OR REPLACEMENT AS PROVIDED HEREIN. CLAIMS BASED ON IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR OR THE SHORTEST PERIOD ALLOWED BY LAW, BUT NOT LESS THAN ONE YEAR. ELECTROLUX SHALL NOT BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES SUCH AS PROPERTY DAMAGE AND INCIDENTAL EXPENSES RESULTING FROM ANY BREACH OF THIS WRITTEN LIMITED WARRANTY OR ANY IMPLIED WARRANTY. SOME STATES AND PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR LIMITATIONS ON THE DURATION OF IMPLIED WARRANTIES, SO THESE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WRITTEN WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE.

If You Need Service

Keep your receipt, delivery slip, or some other appropriate payment record to establish the warranty period should service be required. If service is performed, it is in your best interest to obtain and keep all receipts. Service under this warranty must be obtained by contacting Electrolux at the addresses or phone numbers below.

This warranty only applies in the USA, Puerto Rico and Canada. In the USA and Puerto Rico, your appliance is warranted by Electrolux Major Appliances North America, a division of Electrolux Home Products, Inc. In Canada, your appliance is warranted by Electrolux Canada Corp. Electrolux authorizes no person to change or add to any obligations under this warranty. Obligations for service and parts under this warranty must be performed by Electrolux or an authorized service company. Product features or specifications as described or illustrated are subject to change without notice.

USA 1-877-435-3287

Electrolux Major Appliances North America P.O. Box 212378 Augusta, GA 30907 Canada 1-800-265-8352 Electrolux Canada Corp. 5855 Terry Fox Way Mississauga, Ontario, Canada L5V 3E4